Tumble dryer
Selecta Control

Features and benefits

- The Selecta Control offers a highly accurate electronic cycle and temperature control for unmatched drying performance.
- This contributes to a very fast and highly energy efficient drying cycle and protects sensitive garments from temperature shocks.
- The Selecta Control constantly monitor performance. An advanced self-test programme checks all vital functions to ensure trouble-free operation. Error codes are logged and displayed for easy trouble shooting.
- Possibility for connecting to management systems (e.g.CMIS) via pc.
- The Selecta Control is available with three customized user panels for specific user needs - all ensuring simple and easy operation Coin control (Laundry Shops), AHL control (Apartment House Laundry) and OPL Control (On Premises Laundry).

- **Selecta Coin Control offers:**
  - Button for temperature selection of 4 temperatures.
  - Drying time selection via payment activation, eg. coinmetre, card reader or central payment.
  - Button for Start/stop.
  - Displays: vending price, selected/remaining drying time, cool down time and cycle status.
  - Indicator lamp for heat on.
  - Automatic reverse action (with reversing motor option).
  - Automatic cool down cycle. Adjustment of time and temperature.
  - Automatic buzzer end signal.
  - Automatic anti-crease cycle to prevent creasing and spontaneous combustion if the dryer is not unloaded immediately after cycle end.
  - Automatic display of error codes for easy trouble shooting.
  - Coin and hour counter.

- **Selecta AHL Control offers:**
  - As Selecta Coin.
  - Button for selection of 2 Auto Stop programs for extra dry and dry, or 3 RMC programs (with Residual Moisture Control option).
  - Button for selection of drying time.
  - Displays: selected program or selected time/remaining drying time, cool down time, actual temperature or moisture level (with RMC option) and cycle status.

- **Selecta OPL Control offers:**
  - As Selecta Coin.
  - Button for selection of 5 taylor made programs: 2 Auto Stop programs and 3 time programs, or 9 taylor made programs: 6 RMC programs (with Residual Moisture Control option) and 3 time programs.
  - Button for selection of drying time.
  - Button for adjustment of cool down time.
  - Button for reverse action on/off (with reversing motor option).
  - Displays: selected program or selected time/remaining drying time, cool down time, actual temperature or moisture level (with RMC option) and cycle status.

- Multilevel Service Program for adjustment of a large number of parameters.
  - Level one: change of time per pulse, temperature settings, cool-down time etc.
  - Level two: change of parameters controlling the taylor made programs.

Electrolux

Standard programs for dryers without RMC option

Textile examples	Process	Moisture level	Drying temperature	Cool down temperature	AHL control Program	OPL control Program
Denim	Extra dry	Extra dry	High	45°	P1	P1
100% cotton/polycotton mixture/terry	Ready to put away	Dry	High	45°	P2	P2
All textiles	Time drying 10 minutes		High	45°		P7
All textiles	Time drying 20 minutes		High	45°		P8
All textiles	Time drying 30 minutes		High	45°		P9

Standard programs for dryers with RMC and REVERSING options

Textile examples	Process	Moisture level	Drying temperature	Cool down temperature	AHL control Program	OPL control Program
Denim	Full dry	Extra dry	High	45°	P1	P1
100% cotton/polycotton mixture/terry	Full dry	Dry	High	45°	P2	P2
Polyester/nylon	Full dry	5%	High	45°		P3
Wool/silk	Pre-drying before finishing	10%	High	45°		P4
Viscose/acetate	Pre-drying before finishing/ironing	15%	High	45°	P3	P5
Mixed textiles	Pre-drying before ironing	20%	High	45°		P6
All textiles	Time drying 10 minutes		High	45°		P7
All textiles	Time drying 20 minutes		High	45°		P8
All textiles	Time drying 30 minutes		High	45°		P9

Operating panel

1. Displays program status: **d**=drying, **c**=cool-down, **- -**=anti crease.
2. Program selection button (P-button). Not active on pay machines.
3. Time button: Selection of drying time. Not active on pay machines.
4. Temperature selection button.
5. Symbols for selected temperature.

6. Only for OPL laundries: Reversing on/off.
7. Only for OPL laundries: Setting of cool-down time.
8. Start-/stop button.
9. Heat on indicator.
10. When lamp is lit filter door / filter drawer is open.

Thinking of you

Electrolux

www.electrolux.com/laundrysystems

Share more of our thinking at www.electrolux.com